Sears

Kenmore

SensorSew 70

3 types of buttonhole

needle up and down

reverse stitch

auto-lock stitch

0	1	2	3	4	5	6	7	8	9
A	B	C	D	E	F	G	H	I	J
K	L	M	N	O	P	Q	R	S	T
U	V	W	X	Y	Z	.	_		

MODEL 19501

Sears

Kenmore SensorSew 70

COMPUTERIZED FOR SIMPLICITY

Finger-Touch Easy Sewing

* Straight stitch selected automatically when you turn on the machine.

* Sew every fabric with perfection and ease, using a wide variety of truly useful and attractive patterns.

* Select any pattern by the touch of a finger. Pattern numbers appear on the pattern indicator as you select them.

* Stitch patterns are pre-programmed with the ideal stitch length, width and sewing speed for optimum sewing results.

* Move needle up or down easily by simply pressing the up-down needle position button.

* Combine patterns and the machine will memorize them up to 31, with the memory button. Cancel programming quickly with the clear button.

* Capable of multi-memory for programming pattern combinations and writing sentences. Repeat memorized sequences as many times as you wish.

* Alphabet and numbers, as well as buttonholes, are lock-stitched automatically at beginning and end for durability.